Torque wrench settings

Under The Bonnet	Nm	lbf f
Water pump to cylinder block bolts Fan to water pump bolts Water pump pulley bolts Thermostat housing Engine tie-bar bolts Distributor clamp bolt Upper and lower front swivel pins Track-rod end nut Road wheel nuts Auxiliary driveshaft tensioner bolts Rocker cover bolts Exhaust front pipe to manifold flange nuts	22 9 10 11 22 7 54 30 60 22 5 22	16 7 7 8 16 5 40 22 44 16 4
Transmission		
Front lower suspension-arm pivot bolt nut Swivel hub balljoint domed nut Swivel hub balljoint to suspension arm Track-rod to steering arm balljoint nut Brake caliper retaining bolts Driveshaft retaining nut	45 102 54 30 52	33 75 40 22 38
with multiple split-pin holes in driveshaft with single split-pin hole in driveshaft Flywheel to crankshaft bolt Pressure plate to flywheel bolts Bellhousing cover bolts Engine lower tie-bar bolts	207 255-270 150 25 10 40	153 188-199 111 18 7 30
Suspension, Steering & Brakes		
Front Suspension Driveshaft retaining nut with multiple split-pin holes in driveshaft with single split-pin hole in driveshaft Lower suspension arm pivot bolt nut Upper suspension arm pivot bolt nut Swivel hub balljoint domed nut Swivel hub balljoint to suspension arm Tie-bar to subframe Tie-bar to lower suspension arm Track-rod to steering arm balljoint nut	207 255-270 45 72 102 54 30 26 30	153 188-199 33 53 75 40 22 22 22
Rear Suspension Rear hub retaining nut Radius arm pivot shaft nut	81 72	60 33
Steering Track-rod to steering arm balljoint nut Steering wheel nut Roadwheel nuts	30 47 60	22 33 44
Brakes Brake caliper retaining bolts Disc to drive flange mounting bolts	52 57	38 42
Rear subframe		
Trailing arm inner pivot nuts	72	53